

Wireless Scoring Board

Xian Sun
Firmenich
06/25/2019

Wireless Scoring Board

Main Problem: In Firmenich, there is a blind panel to help researchers analyze the components of products. As blind employees are not able to work by themselves, we need more assistants to do data collection. The whole process is error-prone and inefficient.


Solution: We want to design a physical device that is easier for blind employee to give ratings and send the data to a host computer. It makes the whole process more accurate and efficient.

Wireless Scoring Board

Send Button:
will send data
to master

Sliding bar to give ratings:
Blind employees will slide this
bar to give ratings.

Speaker Button: will
speak out the ratings to
blind employee



Speaker is at the
bottom

Front View

Range from 0.0 ~ 10.0

There is a small bump per 1.0 unit (easier for blind employee to touch)


Instructions :

1. Use sliding bar to give ratings from (0.0 - 10.0)
2. Push Speaker Button to double check if the rating is right
3. Push Send Button to send the data to master
4. After all clients finish rating, the master will process all data.

Other Requirements :

1. At least support 20 client devices at the Same time.
2. The device should be small, light.


The 1st generation Wireless Scoring Board



Example (Client Part) : Blind employee will give ratings to 3 attributes of three products. Everyone has a device to give and send ratings anytime. There is a unique id for each product. For Product1, id is 329.

Three Products : P_{1329} , P_{2028} , P_{3579}

Three Attributes: A_1 , A_2 , A_3



As the data can be sent anytime in any order, let's assume an order of data sent is : 329 028 579 028 329 579 329 579 028

Example (Master Part) : after ratings are done, host computer format and process all data received.

Sequence:

329 028 579 028
329 579 329 579
028

无线评分器上位机

产品数量 3 确认

测试种类 3 确认

测试代号 329 028 579 028 32 确认

串口选择 COM0 打开串口

导出

清空

Open the Device

无线评分器上位机

产品数量 3 确认

测试种类 3 确认

测试代号 579 329 579 028 确认

串口选择 COM4 关闭串口

设备ID: 1	通道: 6	分数: 5.1
设备ID: 1	通道: 5	分数: 10
设备ID: 1	通道: 4	分数: 4.5
设备ID: 1	通道: 3	分数: 6.3
设备ID: 1	通道: 2	分数: 4.9
设备ID: 1	通道: 1	分数: 3.5
设备ID: 1	通道: 6	分数: 7.7
设备ID: 1	通道: 5	分数: 7.9
设备ID: 1	通道: 4	分数: 6.2

导出

清空

Export as Excel

Example (Master Part) : after ratings are done, host computer format and process all data received.

Excel spreadsheet showing data and a summary table, alongside a software interface for wireless rating device data processing.

Excel Spreadsheet Data:

序列号	导入编号	分数
1	329	5.1
2	28	10
3	579	4.5
4	28	6.3
5	329	4.9
6	579	3.5
7	329	7.7
8	579	7.9
9	28	6.2

Summary Table (Highlighted):

产品	特征1	特征2	特征3
产品329号	5.1	4.9	7.7
产品028号	10	6.3	6.2
产品579号	4.5	3.5	7.9

无线评分器上位机 (Wireless Rating Device Host Software) Interface:

产品数量: 3

测试种类: 3

测试代号: 579 329 579 028

串口选择: COM4

设备ID: 1 通道: 6 分数: 5.1
设备ID: 1 通道: 5 分数: 10
设备ID: 1 通道: 4 分数: 4.5
设备ID: 1 通道: 3 分数: 6.3
设备ID: 1 通道: 2 分数: 4.9
设备ID: 1 通道: 1 分数: 3.5
设备ID: 1 通道: 6 分数: 7.7
设备ID: 1 通道: 5 分数: 7.9
设备ID: 1 通道: 4 分数: 6.2

Example (Master Part) : after ratings are done, host computer format and process all data received.

	A	B	C	D	E	F	
1	产品编号1	测评员编号	奶味 (特征1)	咖啡味 (特征2)			
2		1					
3		2					
4		3					
5		4					
6		5					
7		6					
8		7					
9		8					
10		9					
11							
12	产品编号2	测评员编号	奶味 (特征1)	咖啡味 (特征2)			
13		1					
14		2					
15		3					
16		4					
17		5					
18		6					
19		7					
20		8					
21		9					
22							

◀▶ 数据输出 +

Thank you for listening!